




IBERLAMP


# Mounting Instruction

## Product Parameters




1. Model: 123243-60
2. Rated Voltage: AC 100-240V
3. Rated Power: LED 12W
4. IP Grade: IP65
5. Insulation protection level: Class II
6. Operating Temperature: -30~+45°C


## Components and Tools



Flange



Mounting holes



## Installation Steps

<p><b>A</b></p> <p>Drain pipe (2-10x5)</p> <p>Concrete</p> <p>Sand</p> <p>Soil</p> <p>OFF</p> <p>▲ The depth of foundation pit shall be determined by digging to the original soil. In case of backfill, the recessed box can be embedded only after water injection and settlement. ▲ After the concrete setting for 72h (3 days), shall the lamp be mounted only when the concrete is completely solidified.</p>	<p><b>B</b></p> <p>OFF</p> <p>▲ Please be sure to fasten tightly of the flange.</p>	<p><b>C</b></p> <p>▲ Wiring must be operated in accordance with construction specifications.</p>	
<p><b>D</b></p> <p>▲ Make sure the screws be fixed tightly.</p>	<p><b>E</b></p> <p>ON</p> <p>✓</p> <p>▲ Connect the power supply, and light up the lamp.</p>	<p><b>F</b></p>	<p><b>G</b></p>

## Notes:

1. Read this manual of instructions carefully before installation and keep it for future reference;
2. The lamps should be installed or repaired by professional electricians;
3. The light source of this lamp should be replaced by the manufacturer or its service agent or a similarly qualified person;
4. If the external flexible cord of this lamp is damaged, for the sake of avoiding hazard the cord should be replaced by the manufacturer or its service agent or a similarly qualified person;
5. Check the power switch has been turned off before install or repair the lamp.